Remote control functions

Remote control functions for Set-Top Box (STB) operation

- 1. Select TV input source.
- 2. Switch the TV on and off.
- 3. **A, B menus*.**
- 4. Control recording and time-delay mode.
- 5. Access the applications menu.
- 6. Browse the channel guide and confirm.
- 7. Exit menus.
- 8. Control the TV volume.
- 9. Select a channel or type text.
- 10. Get a detailed description of TV program.
- 11. Search for specific content.

- 12. Microphone.
- 13. Switch the STB on and off.
- 14. Access channel guide.
- 15. Android TV main menu.
- 16. Activate voice command*.
- 17. Browse channels.
- 18. Switch volume to mute.
- 19. Activate and deactivate subtitles.
- 20. Back to previous channel.
- 21 Battery status.

*Color menu

A button

Displays navigation menu at the bottom of your screen.

Bbutton

• Opens direct access to the recording menu.

* Voice command

 The voice control function is Google Assistant, which provides access to the set-top box's applications. It does not control CTAL's TV Service. For more information, please visit assistant.google.com.

Helpful hints

 CTAL is in no way responsible for subscriptions to streaming content applications.

